Grounding and Bonding lab

Program: Electrician Technician

Course: EL120 Introduction to Electrical Theory

Objectives: Under the supervision of your instructor, you should be able to do the following:

- Explain the purpose of grounding and bonding and the scope of NEC Article 250
- Define the National Electrical Code® (NEC®) requirements relating to bonding and grounding.
- Distinguish between grounded systems and equipment grounding.
- Use NEC Table 250.66 to size the grounding electrode conductor for various AC systems.
- Explain the function of the main and system bonding jumpers in the grounding system and size the main and system bonding jumpers for various applications.
- Using the proper fitting, connect one end of a bare copper grounding wire to a ground rod, to
 a length of galvanized water pipe, and the other end to the neutral terminal in a main
 panelboard.
- Size the minimum required grounding electrode conductor for a 100A service.
- Properly attach a ground clip to a metal 4S box

Lab Equipment:

- Project board (sheet of plywood or equivalent)
- Armored ground clamps
- Metal 4S box

Required Tools:

- Flat head screwdriver
- Phillips head screwdriver
- Tape Measure
- MC cutter
- Wire cutters

Materials:

• A section of bare grounding electrode conductor wire (8 AWG).



Safety (PPE):

Goggles or safety glasses

Required Time: 300 Minutes

Shop Maintenance:

- All work will cease 20 minutes prior to the end of class.
- All work areas must be cleaned.
- Tools and equipment must be cleaned and returned to the designated areas (cage, tool room, cabinets etc.)
- Any broken or missing tools must be reported immediately.
- Tools and equipment are students' responsibility.

Procedures: (Eye protection must always be worn)

Step #1

- 1. Measure the amount of 8 AWG bare armored copper needed to go from panel to ground rod to water pipe.
- 2. Cut the armored shielding to proper sizes so wire is protected except where it connects to a device or enters the panel. The wire must remain continuous.
- 3. Install one $\frac{1}{2}$ " 2-screw connector into the bottom of the panel.
- 4. Remove enough shielding so that when the copper enters the panel and terminates in the neutral buss that the armored shielding is no longer than
- 5. ½" inch showing on the inside of the panel.
- 6. After connecting to buss, tighten the 2-screw connector.
- 7. Connect two ground clamps on the ground rod in opposite directions so the armored shielding can be secured as the wire enters and exits both clamps.
- 8. Tighten the clamps on the bare copper.
- 9. Terminate one end into the clamp that is mounted on the water pipe.
- 10. Tighten the clamp and have the instructor inspect your work.

Step #2

- 1. Mount a 4-S box on a stud.
- 2. Install a 2-screw connector in one of the KOs on the box 3. Secure a 2' piece of Romex in the clamp, tighten snuggly.



UEI COLLEGE . UNITED EDUCATION INSTITUTE

- 4. Strip the Romex.
- 5. Put a ground clip on the ground, using a flathead screwdriver, resecure to the edge of the box.








Figure 1

Panelboard Installation Diagram



UEI COLLEGE • UNITED EDUCATION INSTITUTE

